


10. PHOTO OF FINAL ASSEMBLY BLOCK



10) FINAL ASSEMBLY BLOCK

Ref. No.	Parts No.	Description	Schematic No.	Q'ty
FRONT PANEL BLOCK				
10-1	BD235710	Front Panel Block Comp.		1
10-2	BD281081	Front Panel Block Comp. (BL)		1
10-3	MZ224627	Push Button Bush A	M2-5004	1
10-4	ZW526577	Collar B, Jack	MC-5006	1
10-5	SE233987	Escutcheon	M2-5430	8
ASSEMBLY BLOCK				
10-6	SD233684	Bottom Plate A	M2-5425	1
10-7x	ZS447840	Tapping Screw #2 3x8(BR)		9
10-8x	SZ645243	Circular Foot A CA	CA-6014	4
10-9x	ZS565942	Tapping Screw #2 4x8(pan)		4
10-10	BC241751	Cabinet	M2-5426	1
10-11x	BC281496	Cabinet (BL)	M2-5426	1
10-12	ZW548010	Spot Facing Washer	MU-6028	4
10-13	ZS510344	Screw, binding head 4x12		4
10-14	SK224886	Power Knob AT-2200	M2-5021	1
10-15x	SK236970	Power Knob (BL)	MU-6320	1
10-16	SK646817	Single Knob	AA-5250	3
10-17x	SK281564	Single Knob (BL)	AA-5250	3
10-18	SB233717	Push Button (Square)	M2-5429	8
10-19x	SB288720	Push Button (Square) (BL)	M2-5429	8
10-20	SK240063	Selector Knob	M2-5428	3
10-21x	SK281597	Selector Knob (BL)	M2-5428	3
10-22	SK241648	Vol. Knob 1	M2-5427	1
10-23x	SK281507	Vol. Knob 1 (BL)	M2-5427	1

When ordering parts, Please describe Parts Number, Description, and Model Number in detail.